



1. Plumb in our tempering valve according to your local codes.
2. Do not sweat connections. Tape all threaded joints with thread sealant.
3. Connect drain to top of tee as close to the hot water source as possible, **our valve** should be in a **horizontal position**.
4. Finish other end of the tee to floor drain, maintain an air gap.
5. Connect cold water, and test.

You must install an anti-hammer device and an approved backflow preventer such as the included double check valve.

See Below for an example

